

TITAN Channel Expander

CMX04HRW-83

Wireless connectivity for multiple Titan Wireless Input Modules

Key Features:

- Supports up to 4 Titan WIFI Recorders (provides Communication & Sync)
- Isolated power supply
- Battery powered operation supported with Battery Monitor
- Records directly to internal memory or to a host PC
- Network interface allows remote operation via TCP/IP or WIFI
- Auto start / Auto record
- Compact size and low weight make the CMX04 suitable for in-vehicle applications



Specifications:

<i>Sample Rate</i>	Up to 5K samples/second (two modules) Up to 2.5K samples/second (four modules)
<i>Recording Media</i>	64GB, non-removable
<i>Synchronization Accuracy</i>	Better than 1.5msec
<i>PC Operation</i>	Via Ethernet or WIFI
<i>Power Requirements</i>	9-18 VDC
<i>Battery Operation</i>	Approximately 4.5 hours
<i>Dimensions / Weight</i>	13.3 cm x 10.6 cm x 4.0 cm (L x W x H) [antenna not connected]

